

Mamiya-Sekor Z Lens

Time (T) Exposure Lock Button



This lens is equipped with a Time (T) Exposure Lock Button.

To make a time exposure, press the T Lock Button and move the T Lever all the way in the direction of the arrowhead, releasing your finger. When this is done, the T Lever will lock in the time exposure position.

Next, press the Shutter Release Button and the shutter will open, remaining in that condition.

To terminate the time exposure, press the T Lock Button and return the T Lever to its original position.

To make another time exposure, simply repeat the above procedure.

Do not touch the Cocking Lever during a time exposure (while the shutter is open). Doing so could result in movement of the film, so exercise care.

- The Shutter Speed Dial of the camera body may be kept at any position during a time exposure. However, after terminating a time exposure the Cocking Lever remains locked for the duration appearing on the Shutter Speed Dial. Thus, if the Shutter Speed Dial were set to 8 sec and a time exposure just terminated, it would not be possible to advance the Cocking Lever until 8 seconds had elapsed. Therefore, to eliminate any inconvenience, we recommend keeping the Shutter Speed Dial at 1/30 sec, or higher, when making time exposures.

Please note that regardless of the length of time exposures, virtually no power is drained from the battery at such a time.



Printed in Japan

マミヤセコールZレンズ

T ロックボタン



このレンズにはタイム露出(T)ロックボタンがついています。

タイム露出をするには、Tロックボタンを押しながら切換えレバーを矢印の方向へいっぱい動かし、手を離してください。切換えレバーがTの位置にロックされます。

この状態でシャッターボタンを押すと、シャッターは開いたままになります。

シャッターを閉じるには、Tロックボタンを押して、切換えレバーを元の位置にもどします。

再度T露出をする場合には、同一の操作を繰り返して行ってください。

T露出中(シャッター開放中)にはセットレバーに手を触れないでください。セットレバーを動かすと、フィルムが送られてしまう場合がありますのでご注意ください。

- T露出をするときに、ボディのシャッタースピードダイヤルはどこにセットしてあってもかまいませんが、遅い秒時にセットしてあると、T切換えレバーをもどしてシャッターを閉じたあと、さらにシャッタースピードダイヤルでセットした秒時が経過するまで、セットレバーがロックされて動かさないことがありますので、シャッタースピードダイヤルは、なるべく速いシャッタースピードにセットしておくことをお勧めします。なお、T露出中は電池はほとんど消耗いたしません。

