

The Prism Finder E is one of several optional interchangeable finders available for the Zenza Bronica ETR. The lightweight and compact finder permits eye-level viewfocusing of a laterally unreversed and erect image which makes it highly satisfactory for general use. The finder shows a very bright image of high magnification and can be used for both horizontal and vertical formats.

The finder field is 40.6 mm x 51.6 mm (or 96% by 94% of the actual picture area) while magnification (with the standard 75 mm lens) is 0.82x.

Attachment and Removal of the Finder



1) The finder attached to the camera, such as Waist-Level Finder E, can be removed very easily. Simply depress the finder release button and, at the same time, slide the finder

to the rear where it can be

lifted off.



be attached to the camera body very easily, too. First, place the protrusions on the bottom of the finder into corresponding openings in the finder frame and, then, slide the finder forward until it locks.

Exchanging the Eyepiece Lens



1) The standard eyepiece lens supplied with the Prism Finder E has a power of -1.50 diopters. When found unsuitable, however, it can be exchanged for one of six optional lenses with powers of -4.50, -3.50, -2.50, -0.50, +0.50 and +1.50 diopters.

Consult your optician for the required eyepiece lens which should be ordered.



2) To exchange the eyepiece lens, first, detach the eyecup. Then, unscrew the setscrew on the eyepiece lens frame which will permit the lens to be removed together with its frame.



3) To attach the replacement eyepiece lens, simply place the bottom edge of the frame into position and then screw in the setscrew at the top of the frame.

Finally, replace the eyecup.

For Mamiya and Bronica medium format cameras and accessories go to : www.ianbfoto.com