



INSTRUCTIONS FOR THE FILM BACK CASE-E

www.ianbfoto.com

The Film Back Case-E should be used for the storage and/or for carrying one spare Film Back and one spare Dark Slide each.

The accessory can be used interchangeably with both Film Back ETR 120 and Film Back ETR 220.



(1) Insert the spare dark slide into its holder inside the case, as illustrated.



(2) Next, insert the spare film back into the case, with the dark slide side placed next to the spare dark slide holder inside the case.

Zenza Bronica Industries, Inc.

25, Minami-Tokiwadai 2-chome,
Itabashi-ku, Tokyo, 174 Japan

Phones: (03) 956-3101, 958-0116

Cable Address: "BRONICA TOKYO"

Telex: 0272-2393 (BRONC J)

Printed in Japan
E.1.4.77