


645AF

Focusing Screen SF402 TypeC

Instructions



Thank you for purchasing a Mamiya product.


When using the M645 lenses, mount the exclusive viewfinder screen (sold separately) and set the focus mode to "M" (manual) to enable shooting with stop down metering.

Before using the product, read the instruction manual thoroughly so that you can use the product properly. After reading, retain the manual in an easily accessible location for future reference.

SF402 TypeC (Matte)


All matte with Fresnel lens.

Ideal for general purpose photography.




Changing The Focusing Screen

1. Remove the lens.
2. Slide the Focusing Screen Release Lever **A**, as illustrated, to the left with the tweezers to let the Focusing Screen down.
3. Remove the Focusing Screen from the Focusing Screen Frame by grasping the tab on the edge of the screen with tweezers as illustrated.
4. In case of attaching, insert your desired Focusing Screen to the Focusing Screen Frame properly and then raise the frame until it clicks.



Caution

- ★ Since the Focusing Screens' surfaces are soft and easily damaged, handle them carefully.
- ★ Never touch the surface with bare fingers. Should dust settle on it, merely blow away by using a blower.
- ★ When cleaning fingerprints on the Focusing Screen, wipe it off by using cloth with light amount of ether or benzene. Do not rub the screen. Since the Focusing Screen is made of Plastic, petroleum based solvents may damage it. Do not use solvents such as ketone and thinner.



Using the M645 Lenses

1. Mount the M645 lens to the body, set the focus, then set the lens' A/M lever to "M". The focus can also be set using the focus mark.
2. Select the exposure mode and set the desired lens aperture.
3. Half-press the shutter release button. The shutter speed is displayed.

	Focus mode			Exposure metering mode			Exposure mode				
M645 lens	Auto focus	Focus aid	Manual	A	S	A-S	P	Av	Tv	M	X
	-	○	○	-	○	-	-	○	-	○	○

- = not an available function

○ = available function

★ With the M645 lens, adjust the exposure by using stop down metering in the Av exposure mode. The proper exposure cannot be achieved in the "P" (program AE) or "Tv" (shutter priority AE) exposure mode.

★ When the M645 lens is mounted, the exposure metering mode is automatically set to "S" (spot exposure metering).

★ Focusing using the focus mark is possible when the lens brightness is F5.6 or brighter.

★ Note that when the lens' A/M lever is set to "M" after the focus mark ● lights and the aperture is stopped down beyond f/ 5.6, the defocus direction marks ► and ◄ flash. This is normal, and requires no adjustments.

Recycled Paper 100%

Mamiya-OP Co., Ltd.

Specifications and appearance are subject change without notice.

Printed in Japan
314474-SI-01E