For Mamiya and Bronica medium format cameras and accessories go to : www.ianbfoto.com


Mamiya Press backs -Changing the pressure plate from 120 to 220

PRECAUTIONS

Make sure the correct surface of the pressure plate corresponds to the film to be used. If it does not match, turn the pressure plate inside out.


Removing the pressure plate:

- 1. Hold the right side edges of the plate as shown in the drawing.
- 2. Remove the plate from the plate catch (B), while pushing it to the direction of the arrow (Fig. 1)



Reattaching the pressure plate:

- 1. Hold the right side edges of the plate as shown in the drawing.
- 2. Insert the pressure plate groove to the left side plate catch (A.(Fig.2-A))
- 3. Hook the right side plate catch (B), while pushing the plate to the direc tion of the arrow. (Fig 2)



ご注意

圧着板の面を,使用フィルムに合わせてく ださい。合っていないときは,圧着板を裏返 しにしてください。


取りはずし方

- 1. 圧着板の右側を,図のように持ちます。
- 2. 矢印方向に押しながら、持ち上げて、ひっかけつめ®をはずします。(図1)
 www.ianbfoto.com

 $\boxtimes 1$

取り付け方

- 1. 圧着板の右側を,図のように持ちます。
- 2. 圧着板のひっかけ用みそを, 左側のひっ かけばね@にはめます。(図2-④)
- 3. 矢印方向へ押しながら、ひっかけつめ B にかけます。(図 2)



For Mamiya and Bronica medium format cameras and accessories go to : <u>www.ianbfoto.com</u>