




Mamiya 7

Mamiya

## Instructions



## External Battery Case PE702

This External Battery Case is designed exclusively for the Mamiya 7, for use in cold weather. It permits the battery to be worn inside your clothing where your body temperature can maintain the battery's voltage.

### Precautions

- ★ The External Battery Case is designed for use with either 6V silver-oxide battery (4SR44), alkaline-manganese battery (4LR44) or lithium battery (2CR1/3) (Same as those used for Mamiya 7 Camera).
- ★ It is advisable to use a fresh battery.

### How to Use

1. Remove the battery from the camera. (Be careful not to lose the battery chamber cover.)
2. Insert the battery into the External Battery Case, making sure to maintain proper polarity. ( Fig 1 )
3. Separate the External Battery Case and the Dummy Battery by disconnecting the Connector and screw the Dummy Battery into the battery chamber of the Camera.( Fig 2,3 )
4. Reconnect the cord again.
5. When not using the camera, disconnect cord and keep External Battery Case inside your clothing.

#### Note:

When disconnecting, do not pull on the cord but handle the connectors only.  
Cold temperatures can affect camera operation, too. Please see camera instruction manual regarding cold weather photography.

英語

Printed in Japan  
25750-RB-03E