



Mamiya Leaf

Mamiya Leaf Battery Charger for 645DF+ Li-ion Battery

User Guide

www.ianbfoto.com

Mamiya Leaf Charger for 645DF+ Li-ion Battery

USER GUIDE

To charge your Mamiya Leaf Li-Ion Battery for 645DF+:

1. Connect the Charger to a power outlet using the included 12 V power supply with the appropriate international outlet adapter.
2. Place the Battery firmly in the charger.
When properly connected, the LEDs indicate the status of the charge:

LED Color	LED Status	Comment
Red	Steady	Charging
Green	Steady	Fully charged
Red	Flashing	Error

3. Charging is complete when the LED is steady green.

IMPORTANT SAFETY INSTRUCTIONS AND WARNINGS

Please read these safety instructions and warnings carefully before using the charger and keep this document for future reference.

General Guidelines and Warnings

Stop using or charging the battery immediately if it becomes damaged, gives off an odor, becomes deformed, starts to balloon or swell up, leaks, its temperature reaches over 70°C (160°F) or anything else abnormal occurs.

Only use the Mamiya Leaf Charger to charge original Mamiya Leaf Li-Ion Batteries for 645DF+. Failure to do so can cause a fire which can result in personal injury and property damage. Always allow it to cool down to ambient temperature before charging.

Never charge the battery unattended. Do not let the temperature exceed the range from 0°C to 45°C (32°F to 113°F). You should always monitor the battery during the whole charging process. Never charge the battery inside a car or in extreme temperatures. Extremely high temperatures might ignite the battery and cause a fire.

During the warranty period, if this product is found to be defective, return it to your supplier or vendor.

Product Warranty

Mamiya Leaf warrants this product against original defects in material or workmanship for one year from the day of purchase. The warranty does not cover products which are misused, mishandled, dropped or inappropriately used. The warranty does not cover collateral damage like damage to camera body, digital backs and laptops or loss of data.

REPAIR OR REPLACEMENT PROVIDED UNDER THIS WARRANTY IS THE EXCLUSIVE REMEDY FOR THE CONSUMER. PHASE ONE SHALL NOT BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES FOR BREACH OF ANY EXPRESS OR IMPLIED WARRANTY ON THIS PRODUCT, EXCEPT TO THE EXTENT PROHIBITED BY APPLICABLE LAW, ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE ON THIS PRODUCT IS LIMITED IN DURATION TO THE DURATION OF THIS WARRANTY.