


Mamiya L-Grip Holder RZ



This grip can be used for holding the camera with your left hand to provide a firm support and maintain camera stability. It is also convenient for carrying the camera.

Because the shutter release button on the grip is interlocked with the camera's electromagnetic release, you can trip the shutter with a light touch.

Attaching the grip to the camera

1. Put the mounting screw on the grip into the tripod socket on the camera and tighten in securely.
2. Insert the connecting plug of the grip into the auxiliary shutter release socket on the RZ67.

How to use

1. Turn the release/lock ring on the grip and align the release/lock mark (red dot) with the release mark (white dot).
2. Set the shutter release selector on the RZ67 camera body to the normal position (white dot).

If the camera's shutter release is set for the mechanical shutter (orange dot), the shutter will not trip when you depress the shutter release button on the grip.

3. The shutter can be tripped by depressing either the shutter release button on the grip or the shutter release button on the camera body.

Release lock

The shutter release button on the grip can be locked by turning the release/lock ring and setting the release/lock mark (red dot) to the lock mark (red dot). However, the shutter release button on the camera will activate even if the grip button is locked.

If you are not using the camera, be sure to lock it by setting its shutter release selector to the red dot to prevent accidental shutter activation.

- * A plug compartment is provided to store the connecting cord when it is not in use.
- * The hand strap can be adjusted by loosening the adjusting screw with a coin.