

## Mamiya ZD

### Coupler Kit PD301 for Mamiya ZD

AC電源用カプラーキット PD301


[www.ianbfoto.com](http://www.ianbfoto.com)

Thank you for purchasing a Mamiya product. The Coupler Kit PD301 enables the Mamiya ZD to be powered by a household AC outlet in combination with the AC Adapter PA302. You need not use a battery and worry about the remaining battery level.

#### Part Names


##### DC coupler

- ① DC Terminal
- ② Positive terminal
- ③ Negative terminal



##### Cover for the DC coupler

- ① Lock lever
- ② Cover Latch




#### Specifications


Compatible camera: Mamiya ZD  
 Operating temperature: 0 to +40°C  
 Rated input: 7.0 VDC  
 Rated output: 7.0 VDC

Instructions  
 使用説明書


### Setting and connecting of the Coupler Kit PD301




1. Turn off the camera body.  
 ★ For safety, it is recommended to detach lens from camera body and attach the camera body cap that is supplied with the camera body before proceeding to next.




2. Press and slide the lock lever ① of the Battery Cover as indicated by an arrow, and open the battery cover.




3. Press and hold the white Battery Lock Knob ③ of the camera body, and remove the battery from the compartment.




4. Slide the Cover Latch ②, and detach the Battery Cover from the camera body.




5. Slide and hold the Cover Latch ②, and attach the Cover for the DC coupler to the camera body.



6. Insert the DC Coupler into the camera's battery compartment.  
 ★ Make sure the DC Coupler is secured by the Battery Lock Knob.



7. Close the Cover for the DC Coupler after positioning the cord so that it is lead out through the notch on the cover.



8. Connect the DC Terminal ① of the DC Coupler and the DC Plug of the AC Adapter PA302.

- ★ Make sure the camera is switched off before connecting with the AC Adapter PA302.
- ★ After you finish using the camera, unplug the power cord from the AC outlet.
- ★ In the event of any abnormality, please take the Coupler Kit and AC adapter to your camera distributor or customer service.

#### Handling precautions

- The coupler Kit PD301 is designed exclusively for the use with the Mamiya ZD.
- Do not connect the AC Adapter PA302 and Coupler Kit PD301 before installing the coupler kit in camera body.
- When camera is not in use, unplug the power cord from the AC outlet.

Mamiya

100% Recycled Paper

Mamiya-OP Co., Ltd.

仕様外観は品質向上のために予告なく変更する場合があります。  
 Specifications and appearance are subject to change without notice.

Printed in Japan  
 206520-EL-01JE